

When you sit on an upholstered piece of furniture, comfort is crucial. And that's where Recron® Fibrefill plays a vital role. With its high bulk and outstanding loft, Recron® Fibrefill makes sure your body gets great support and comfort. Plus, it provides aesthetic appeal, durability and value for money.

What's more! Recron® fibrefill also makes you feel cool, thus avoiding the heat that you normally feel when you sit on furniture made of only PU foam or latex foam cushions.

You can use Recron® Fibrefill to make

- Firm seat cushion with wadding made of **15 Denier Thermobond (Non - Siliconised)** wrapped on PU or latex foam cushion
- Firm and silky back cushion directly filled with opened fibre of 15 Denier hollow siliconised.
- Firm and silky side arm directly filled with opened fibre of 15 Denier hollow siliconised

Please Note: Usually 51mm or 64mm fibres are used, except for machine blown filling, where 32mm fibres are recommended.



Reliance