

Use leather and textile garments filled with an interlining of high loft waddings made out of Recron® Fibrefill and enjoy the warmth you need.

Recron® Fibrefill also helps your garments stay in their original shape.

You can also make garments for different weathers like moderate cold, extreme cold etc by varying the grams per square meter (gsm) of the wadding used.

The types of Recron® Fibrefill used to produce high loft waddings for garments are:  
6 /15 Denier hollow non-siliconised for chemical bonded waddings  
6/15 Denier hollow non-siliconised thermobond for thermal bonded waddings

Normal cut length used: 51 or 64mm

